



custom solutions for all budgets

To Change Time and Temperature on a Press with EzWizard 2.41 Software

1. Turn off the press, wait 5 seconds and turn it back on while holding in the triangle key
2. Keep holding in the triangle key until the screen displays E2.41, then release the triangle key
3. Tap the triangle key 3 times to display the seconds screen – now tap the + or - key to increase or decrease the seconds. (+ plus key is 2nd button and – minus key is third button on the bottom)
4. Tap the triangle key one more time (4 times total) to display the temperature screen ±380, now tap the + or – key to increase or decrease the temperature.
5. Turn the press off, wait 5 seconds and turn it back on. These will be the new default settings.

Proudly made in the USA

**612 North Florida Avenue, Wauchula, FL 33873
863.767.0155 • tollfree: 877.906.1818 • fax: 863.767.0346**

www.EzPi.us